






















Refill ink cartridge

No.	Photo	Model	Color	Use for on
1		HP564	5C	HP Photosmart C5324/C5370/D5460/ D5463/ D5468/C6380
2		HP920	4C	HP920/HP6000/HP700 0
3		985-A5	4C	Brother MFC790CW/290CW/ 490CW/5490CN/250C DCP145C/165C/385C/ 585CW/185C
4		1240-A3	4C	LC73/LC75/LC77/LC7 9/LC1280
5		1240-A6	4C	LC73/LC75/LC77/LC7 9/LC1280
6		HP10/11 AA	4C	HP88/HP1000/HPK550 /HP1100/K850/HP120/ HP130
7		L731- M09	4C	Epson C90/T11/CX3900/ CX5900/CX7300/ CX5500

8		L731-M09	5C	Epson C110/T30
9		L731-M09	6C	Epson R270/T50/T60
10		T1281-M09	6C	Epson C90/T11/CX3900/ CX5900/CX7300/ CX5500
11		T1281-M09	5C	Epson C110T30
12		T1281-M09	6C	Epson R270/T50/T60
13		L63-M06	4C	Epson C63/C64/C65/C67/R25 0/ CX4500/CX6500
14		L63-M06	6C	R1800/R800

15		EP5852	5C	Epson PI200/210/240/250/260/ 270/280/290
16		5BK/8CP	4C	Canon IP4000/IP5000
17		5BK/8CP	5C	Canon IP4200/IP4300/IP4500 / IP5300/MP500/IP800/ IP950/IP830
18		520/521	5C	Canon IP4600/4800/3600/ MP988/MP638/MP545
19		HP801	6C	HP8238/3108/3308/ C5188/C618/D7168/ D7368
20		T7011	4C	WorkForce PRO WP4025/WP4515/WP 4525/WP4535/WP4545
21		1240-A5	4C	BROTHER MFC- J6510DW/ J6710DW/J6910DW
